

ULTIMA A6
User Manual






Parts Name



PARTS





How to Operate

-Battery Mode How to interchange the battery





(1):unscrew the cover of plug (picture 1)(2):replace the battery (picture2)

How to charge the battery





4

(1):put the battery into the charger (picture3)(2):Plug in DC adaptor to the jack and then connect power supply (picture 4)



—Indicator light

The indicator light is red while charging.
 The indicator light is green after fully charged

Charger



How to Operate

-Adapter Mode

(1) Assemble the cover of plug. (picture 5) (2) Plug DC adaptor to the jack. (picture 6) (3) Plug in DC adaptor to AC outlet.





(

How to install a cartridges

- (1)Take out needle cartridges in the sterilized packing.
- (2)Fitting round slots 1 into 2 of machine, push needle cartridges horizontally up to the end. (3)Lock the cartridge by turning it to the counter
- clockwise.

 (4)Adjustment of needle length should be done after turn on the machine.
- (5)If you want to remove the needle cartridge, turn it to the clockwise and push out horizontally, fittting round slots(slot1.slot2)together.





How to Operate

(3)Adjustment of needle length

You can adjust the length of needle by turning the adjustment ring clockwise or counter clockwise. Turning it clockwise, Indied it clockwise, length of it will be longer. Turning it counter clockwise, length of it will be shorter.

Needle length adjusting point





How to Operate

3.Adjustment of speed and needle length (1)Adjustment of Speed and ON/OFF



(2) 5 speed level control

Pressing the switch 2 seconds to open the device. It starts from the lowest speed to highest speed when you turn on the power firstly. The speed cycles low to high. Please press the switch 2 secondswhen you need to stop the device.

The flicker frequence of light faster, the speed is higher



Specification

1.Object

Apparatus for applying a Micro-needle Therapy by vibration

2.Performance

A device for puncturing skin-penetrating drugs or cosmetics supports witth a micro-needie guided between extended and retracted positions.

3. Specification

1)Product name: Auto-stamp Motorizedmeso Machine

2)Model name: Ultima A6 3)Adapter: 5V,1000mA 4)Weight: Main body 62g 5)Size: 126*23(mm)

4.Packing list

1 pcs				
2 pcs				
1 pcs				
1 pcs				
2 pcs 12 pins				
1 pcs				



Maintenance

1. General maintenance

- -Keep it with its power off. Wipes its surface out with a dry cloth.
- -Keep it away from directly sunlight or high temperature and humidity.
- -Do not leave the measurement, repair or alter of the device to non-professional staff. 2. Routine inspection
- -Make sure to inspect the device and adapter before use.
- -When you use the device which has not been used for a long time, make sure to check if it works properly with safety.

\Diamond	Please be sure to read instructions before use and follow as described.			
<u> </u>	Do not apply it to the man as follow: 1 Who has acute disease or bloody disease over 38 °C 2 Who has alley and hemophils 3. Who has melancais of the face 5. Who regularly with the hoppid 6. Who takes melidines 7. Who is guident 12 years old			
\Diamond	Do not use it on the power other than AC 220V. It may cause fires or malfunction			
0	Do not use it near the place with high temperature, dust or humidity (Near the humidifier). It may cause malfunction.			
\bigcirc	Do not repair, disassemble or after the controller and the body. It may cause malfunction.			
\Diamond	Do not touch the device or detach the power cords with wet hands. It may cause electric shock.			
0	Do not use the stripped cord or propped cord. It may cause fires(Be sure to replace it with another).			
\Diamond	Do not use the propped cord which has crack or scares. It may cause scares on the skin.			
0	When you don't use it for a long time, unplug it from the outlet.			
0	Be sure to have an inspection for test. If any troubles are found, get it repaired.			



Precaution

\sim	Alternating current	SN	Serial No
	Direct current	ac inp	EU Representative
	Class II equipment	Œ	CE mark
Δ	Attention, consult accompanying documents	mal .	Manufacturer
쎈	Date of manufacture	F	Floating applied part



Warranty

- 1. We guarantee the products as follow.
- We offer free repair to our products within 6 months basis(warranty) from the day they are purchased. If any of our products has damages or natural trouble, we offer repairs or replacements.
- If they are included in the following problems, you have to pay for the repair even during warranty period.
- -Troubles due to a user's careless treatment, voluntary repair or alteration
- -Trouble due to the repairs by a man other than techician from a dealer shop or the customer center appointed by manufacturer
- -Troubles or damages due to shocks while in movement
- -Trouble due to the accessories or options not appointed by manufacturer
- -Trouble due to other natural disaster(fires,salt or water,etc)